

## Coffee Scrub Stick

ID	BODY Cleansing / 700445.0021	ID-No: 004.001
pH-value	---	
Appearance	White Stick with Exfoliants	
Product Form	Stick	
Claims	Exfoliating; Cleansing; Caring; Microplastic-free	

St	Substance	INCI Name USA	% w/w	Manufacturer
1	Tego Alkanol 1618	Cetearyl Alcohol	27.60	Evonik, DE
	TEGO Feel C 10	Cellulose	1.00	Evonik, DE
	Sisterna A10E-C	Sucrose Tetrastearate Triacetate	2.50	Sisterna B.V., NL
	Dermofeel Sensolv	Isoamyl Laurate	3.00	Evonik, DE
	Coconut Oil refined, organic	Cocos Nucifera (Coconut) Oil	3.00	All Organic Trading GmbH, DE
	Cacao Butter Pellets	Theobroma Cacao (Cocoa) Seed Butter	2.00	Henry Lamotte Oils, DE
	Tego SMO V	Sorbitan Oleate	0.20	Evonik, DE
	Virgin Prunus Oil	Prunus Domestica Seed Extract	5.00	Laboratoires Expansion-science, FR
	Organic Cold Pressed Coffee Bean Oil	Coffea Arabica (Coffee) Seed Oil	2.00	Biopurus, GB
	Dermosoft GMCY	Glyceryl Caprylate	0.50	Evonik, DE
	Dermofeel Toco 70 non-GMO	Tocopherol, Helianthus Annuus (Sunflower) Seed Oil	0.20	Evonik, DE
2	Amisoft GS-11P	Sodium Stearoyl Glutamate, Sodium Cocoyl Glutamate	20.00	Ajinomoto, JP
	Elfan AT G	Sodium Cocoyl Isethionate	30.00	Akzo Nobel Chemicals GmbH, DE
	Peeling Powder	Several	1.00	several
3	Cappucino	Fragrance	2.00	Mystic Moments UK, GB

### Production

Prepare 1 and heat to between 60-70°C / Prepare 2 / When 1 is fully melted, add 2 and stir for 3-5 minutes to make a homogenous mixture / After 3-5 minutes and before homogenizing, add 3 / Homogenize for 1 minute. It helps to warm up the homogenizer so that your mixture doesn't solidify upon contact with a cold homogenize / Pour into moulds and leave to cool to room temperature.

**Stability:** Stable for more than 3 months at 5°, 25° and 40°C

**Microbiological Stability:** ---

### Disclaimer

Utilisation of this document or parts thereof as well as product names for commercial or industrial applications is subject to explicit written approval by RAHN AG. This information is based on our own experience to date and we believe it to be reliable. It is intended only as a guide to use at your discretion and risk. We cannot guarantee favourable results and we assume no liability in connection with its use, or the use of the methods or products described. None of this information is to be taken as a license to operate under, or a recommendation to infringe, patents.

Version: 05/2020