

## Moisture Energising Cream

|              |                         |                |
|--------------|-------------------------|----------------|
| ID           | FACE Care / 700064.0002 | ID-No: 001.001 |
| pH-value     | Approx.: 6.3            |                |
| Appearance   | White emulsion          |                |
| Product Form | Emulsion O/W            |                |
| Claims       | Moisturising; Caring;   |                |

| St | Substance               | INCI Name USA                                                                                                                   | % w/w | Manufacturer             |
|----|-------------------------|---------------------------------------------------------------------------------------------------------------------------------|-------|--------------------------|
| 1  | Water demin.            | Water                                                                                                                           | 71.70 | several                  |
| 2  | Carbopol Ultrez-10      | Carbomer                                                                                                                        | 0.15  | Lubrizol, US             |
|    | Carbopol Ultrez-20      | Acrylates/C10-30 Alkyl Acrylate Crosspolymer                                                                                    | 0.15  | Lubrizol, US             |
| 3  | Tegosoft OS             | Ethylhexyl Stearate                                                                                                             | 7.00  | Evonik Industries AG, DE |
|    | Tegosoft CI             | Cetearyl Isononanoate                                                                                                           | 7.00  | Evonik Industries AG, DE |
|    | Sisterna SP30-C         | Sucrose Distearate                                                                                                              | 3.00  | Sisterna B.V., NL        |
|    | Cetiol OE               | Dicaprylyl Ether                                                                                                                | 2.00  | BASF, DE                 |
|    | Verstatil PC            | Phenoxyethanol, Caprylyl Glycol                                                                                                 | 1.00  | Dr. Straetmans, DE       |
|    | Sisterna SP70-C         | Sucrose Stearate                                                                                                                | 1.00  | Sisterna B.V., NL        |
|    | Keltrol CG-SFT          | Xanthan Gum                                                                                                                     | 0.20  | CP Kelco, US             |
| 4  | L-Arginine solution 10% | Water, Arginine                                                                                                                 | 3.00  | Ajinomoto, JP            |
| 5  | Perfume Vital N123      | Fragrance                                                                                                                       | 0.80  | Huber the Nose, CH       |
| 6  | HYDRACTIN®              | Glycerin, Water, Disodium Adenosine Triphosphate, Carica Papaya (Papaya) Fruit Extract, Phenoxyethanol, Algin, Sodium Hydroxide | 3.00  | RAHN AG, CH              |

### Production

Prepare 1 / Mix 2, add to 1 while stirring, heat to 70°C / Mix 3, heat to 70°C, add to 1/2 while stirring / Add 4 while stirring, homogenise / Cool to 40°C while stirring / Add the remaining ingredients separately while stirring, homogenise / Cool to 25°C while stirring

**Stability:** Stable for more than 3 months at 5°, 25°, 40°C

### Disclaimer

Utilisation of this document or parts thereof as well as product names for commercial or industrial applications is subject to explicit written approval by RAHN AG. This information is based on our own experience to date and we believe it to be reliable. It is intended only as a guide to use at your discretion and risk. We cannot guarantee favourable results and we assume no liability in connection with its use, or the use of the methods or products described. None of this information is to be taken as a license to operate under, or a recommendation to infringe, patents.

Version: 02/2014