

## PROTEOLEA<sup>®</sup> Skin Rebalancing Night Cream

ID	FACE Care / 700062.0001	ID-No: 001.001	
pH-value			
Appearance	Slightly beige emulsion		
Product Form	Emulsion W/O		
Claims	Anti-Ageing; Protecting; Regenerating; Microp	ng; Regenerating; Microplastic-free	

St	Substance	INCI Name USA	% w/w	Manufacturer
1	Water demin.	Water	67.30	several
	Sodium Chloride	Sodium Chloride	1.00	several
	Citric Acid solution 10%	Citric Acid, Water	1.00	several
	Sodium Sulfite	Sodium Sulfite	0.20	several
	Glycerin 85%	Glycerin, Water	2.00	several
2	Sympatens W/4500	Sorbitan Oleate, Polyglyceryl-3 Polyricinoleate	5.00	Kolb Distribution Ltd., CH
	Cetiol SN	Cetearyl Isononanoate	6.00	BASF, DE
	Isohexadecane	Isohexadecane	7.00	Lanxess Distribution, DE
	Cetiol OE	Dicaprylyl Ether	5.00	BASF, DE
	Magnesium Stearate	Magnesium Stearate	0.50	several
	Sisterna SP01-C	Sucrose Polystearate	0.50	Sisterna B.V., NL
	Genuvisco CG-131	Chondrus Crispus (Carrageenan)	0.20	CP Kelco, US
	Euxyl PE 9010	Phenoxyethanol, Ethylhexylglycerin	0.50	Schuelke & Mayr, DE
	Cutina HR	Hydrogenated Castor Oil	1.50	BASF, DE
3	Perfume Silky XCN78	Fragrance	0.30	Huber the Nose, CH
4	PROTEOLEA <sup>®</sup>	Glycerin, Water, Fructan, Decyl Glucoside, Olea Europaea (Olive) Leaf Extract, Phenethyl Al- cohol, Ziziphus Jujuba Seed Extract, Citric Acid, Ascorbic Acid	2.00	RAHN AG, CH

## Production

Prepare 1, heat to 80°C / Mix 2, heat to 80°C, add 1 to 2 very slowly while stirring, homogenise / Cool down to 40°C while stirring / Add the remaining ingredients separately while stirring, homogenise / Cool to 25°C while stirring, homogenise.

Stability: Stable for more than 3 months at 5°, 25°, 40°C Microbiological Stability: ---

## Disclaimer

Utilisation of this document or parts thereof as well as product names for commercial or industrial applications is subject to explicit written approval by RAHN AG. This information is based on our own experience to date and we believe it to be reliable. It is intended only as a guide to use at your discretion and risk. We cannot guarantee favourable results and we assume no liability in connection with its use, or the use of the methods or products described. None of this information is to be taken as a license to operate under, or a recommendation to infringe, patents. Version: 04/2020