

PIXEL PERFECT

- Anti-Imperfections Complex •

With

Pixelia[®] & **Sweetone**[®]

**A daily Anti-Blemish skin care for
Untouched Beauty**

PIXEL PERFECT Anti-Imperfections Complex is the ideal face care that helps to regain a perfectly homogenous skin by reducing imperfections, with a pixel precision.

The combination of precious active molecules from **Pixelia**[®]/**Sweetone**[®] offers a dual soothing/unifying effect for a purified and sublimated skin.



Light emulsion, daily applied on the face, by insisting on areas prone to redness, acne and other imperfections

A duo of natural active molecules

PIXALIA[®]

Concentrate of active molecules exclusively obtained from the dry leaves of *Cleome gynandra*, **PIXALIA**[®] acts on the entire iterative cascade of acne: **QUANTITY & QUALITY** of the sebum and **INFLAMMATION**.

SWEETONE[®]

SWEETONE[®] modulates **NEUROGENIC INFLAMMATION, NON-SPECIFIC and VASCULAR INFLAMMATION**. It thus limits the emergence of skin imperfections and soothes sensitive skins.

PIXALIA® & SWEETONE® in PIXEL PERFECT

• Anti-Imperfections Complex •

A	DEIONIZED WATER	Aqua		73,55%
	EDETA BD	Disodium EDTA	BASF	0,10%
	RHODICARE T	Xanthan Gum, Aqua	SACI-CFPA	0,20%
	CHLORPHENESIN BP 73	Chlorphenesin, Aqua	AZELIS	0,25%
	AQUEOUS SOLUTION OF NaOH 10%	Aqua, Sodium Hydroxide		1,30%
B	SENSANOV WR	C20-22 Alkyl Phosphate, C20-22 Alcohols, Aqua	SEPPIC	3,00%
	LANETTE 16	Cetyl Alcohol	BASF	0,60%
	LANETTE O OR	Cetearyl Alcohol	BASF	0,70%
	REFINED MACADAMIA OIL (BCE 1010)	Macadamia Integrifolia Seed Oil	BIOCOSMETHIC	6,00%
	TEGOSOFT OER	Oleyl Erucate	EVONIK GOLDSCHMIDT UNIVAR	5,00%
	XIAMETER® PMX-200	Dimethicone	UNIVAR	0,50%
	SILICONE FLUID 100CS			
	CELLULOBEADS USF	Cellulose, Aqua	DAITO KASEI	1,00%
C	PHENOXYETOL	Phenoxyethanol	CLARIANT	0,80%
D	DEIONIZED WATER	Aqua		2,00%
	SWEETONE®	Schisandra Sphenanthera Fruit Extract, Maltodextrin	LABORATOIRES EXPANSCIENCE	0,50%
E	PIXALIA®	Propanediol, Aqua, Rutin, Hydroxycinnamic Acid	LABORATOIRES EXPANSCIENCE	3,00%
	VITAMINE E ACETATE CARE	Tocopheryl Acetate	BASF	0,10%
	AQUEOUS SOLUTION OF NaOH 10%	Sodium Hydroxide, Aqua		0,20%
	PARFUM LOTUS BLANC SA FML00118	Parfum	Mlle Parfumette ACCORDS & PARF	1,20%

Instructions

1. Weigh water and EDETA BD. Stir and heat.
2. At 50°C, sprinkle in Rhodicare T and heat to 75°C. Add the other ingredients for phase A.
3. Weigh the components for phase B except the Cellulobeads. At 75°C, sprinkle in the Cellulobeads and keep stirring for 10 min.
4. Place phase B under an Ultra-Turrax for 30 s at 8500 rpm.
5. Add phase B to phase A, then start to cool. At 72°C, place the mixture under the Ultra-Turrax for 30 s at 9,500 rpm.
6. Add phase C after cooling to 50°C under the Ultra-Turrax at 1,000 rpm.
7. At 35°C, sprinkle Sweetone® into the water, stirring.
8. Add phases D and E to the final product.
9. Measure the pH and adjust, if necessary, with the sodium hydroxide at 10% 5.80<pH<6.20.

Laboratoires Expanscience
10, avenue de l'Arche, 92419 Courbevoie Cedex – France
Tél.: + 33 (0) 1 43 34 60 00 – Fax: + 33 (0) 1 43 34 61 00
www.expanscience.com